
Best Practice Guide 3 (Issue 3)

**Connecting a
microgeneration
system to a
domestic or
similar electrical
installation**

*(in parallel with the
mains supply)*



Best Practice Guide

Electrical Safety First is indebted to the following organisations for their contribution and/or support to the development of this Guide:



BEAMA
www.beama.org.uk



British Gas
www.britishgas.co.uk



Certsure
www.certsure.com



City & Guilds
www.cityandguilds.com



ECA
www.eca.co.uk



ENA
www.energynetworks.org



HSE
www.hse.gov.uk



Institution of Engineering and Technology
www.theiet.org



NAPIT
www.napit.org.uk



SELECT
www.select.org.uk



SPACES
www.thespaces.org.uk



Sundog Energy
www.sundog-energy.co.uk

Several of the photographs in this Guide have been extracted from a superseded Electrical Safety First DVD, courtesy of Navigator Productions Ltd. Others were kindly supplied by Nick Blakeley Electrical and Bradford Metropolitan District Council.

This is one of a series of Best Practice Guides produced by Electrical Safety First* in association with leading industry bodies for the benefit of electrical contractors and installers, and their customers.

In electronic format, this Guide is intended to be made available free of charge to all interested parties. Further copies may be downloaded from the websites of some of the contributing organisations.

The version of this Guide on the Electrical Safety First website (www.electricalsafetyfirst.org.uk) will always be the latest. Feedback on any of the Best Practice Guides is always welcome – email bpg@electricalsafetyfirst.org.uk

Electrical Safety First is supported by all sectors of the electrical industry, approvals and research bodies, consumer interest organisations, the electrical distribution industry, professional institutes and institutions, regulatory bodies, trade and industry associations and federations, trade unions, and local and central government.

*Electrical Safety First (formerly the National Inspection Council for Electrical Installation Contracting) is a charitable non-profit making organisation set up in 1956 to protect users of electricity against the hazards of unsafe and unsound electrical installations.

Electrical Safety First
The UK's electrical safety experts

Published by:

Electrical Safety First
Unit 331
Metal Box Factory
30 Great Guildford Street
London SE1 0HS

Tel: 0203 463 5100

Email: bpg@electricalsafetyfirst.org.uk

Website: www.electricalsafetyfirst.org.uk

Electrical Safety First and other contributors believe that the guidance and information contained in this Best Practice Guide is correct, but all parties must rely on their own skill and judgement when making use of it. Neither Electrical Safety First nor any contributor assumes any liability to anyone for any loss or damage caused by any error or omission in this Guide, whether such error or omission is the result of negligence or any other cause. Where reference is made to legislation, it is not to be considered as legal advice. Any and all such liability is disclaimed.

© Electrical Safety Council. November 2015

Connecting a microgeneration system to a domestic or similar electrical installation

(in parallel with the mains supply)



Photo courtesy of Sundog Energy Ltd

The aims of this Guide are:

- to provide an overview of microgeneration intended to produce electrical energy, otherwise known as small-scale embedded generation (SSEG),
- to provide information on the legal and contractual issues relating specifically to the installation of microgenerators with electrical rating up to 16 A per phase (including the relationship of the consumer with the electricity supplier and the distribution network operator (DNO)), and
- to give guidance on the particular electrical issues, including electrical safety issues, that arise when installing or connecting a microgenerator.

The Guide does not provide installation guidance specific to any particular types of microgeneration. Section 712 of BS 7671 contains particular requirements for photovoltaic installations, as does the Code of Practice for Grid Protected Solar Photovoltaic Systems published by the Institution of Engineering and Technology in 2015. For any microgenerator installation, the instructions of the manufacturer or supplier should be followed.

The Guide does not provide installation guidance where it is intended to install more than one microgenerator. In such cases it is necessary to consider the possibility of interaction between the protection and control equipment of the microgenerators, and the specific advice of the manufacturers or suppliers of each of the microgenerators should be obtained and followed.

Where multiple microgeneration installations are to be installed in a close geographical region (such as in a housing development), it is also necessary to obtain the permission of the Distribution Network Operator (DNO) in advance.

Guidance on getting a generation scheme connected to the distribution network can be found in the DG Connection Guides published by the Energy Networks Association (ENA). These may be downloaded from:

www.energynetworks.org/electricity/engineering/distributed-generation/dg-connection-guides.html



Photo courtesy of Sundog Energy Ltd

The Guide does not cover Feed-in Tariffs. On 1 April 2010 the Government launched Feed-in Tariffs (FITs), which are payments to microgenerators based on both what they generate, and what they export to the grid if they choose to do so. More information on FITs is available from www.energysavingtrust.org.uk

To be FIT-eligible, electricity-led microgenerator installations with a Declared Net Capacity of 50 kW or less must conform to the Microgeneration Certification Scheme (MCS). Other schemes may in future be approved as being equivalent.

For an installation to be MCS compliant both the equipment being used and the installation company must have been certificated by a UKAS accredited Certification Body. Much of the equipment used in an installation will have been tested against MCS performance, quality and safety standards before being certified. (Details of MCS standards are available on their website.)

For an installation company to become certificated, a Certification Body will assess its technical competence, as well as checking that it has appropriate business processes (such as quality standards, complaints handling procedures etc). In order to become MCS certified, installation companies must be members of the Renewable Energy Consumer Code (or an equivalent).

More information on becoming an MCS installer, and on what equipment is currently approved under the scheme, is available from www.microgenerationcertification.org

Introduction

The UK Government is committed to encourage the wider use of renewable energy generation, and to technologies such as combined heat and power (CHP) that offer improved efficiency compared to traditional bulk generation in large power stations.

This commitment reflects undertakings made with the UK's partners in the European Union and internationally to reduce greenhouse gas emissions and reliance on fossil fuels.

Generation of electricity closer to the point of use avoids some of the losses that arise in the transmission and distribution of electricity to consumers. This currently amounts to up to 10% of units dispatched. Even for the most modern combined cycle gas generating stations with production efficiencies of 50-60%, the efficiency from the point of generation up to the point of use in a consumer's installation is generally well below 50%.

Decentralised generation, if sufficiently widely adopted, could also improve the reliability and resilience of the electricity supply system, though this clearly depends on the types and relative amounts of generation that are installed. For example, photovoltaic systems do not generate at night, and wind power does not function at very low or very high wind speeds.

Over the past few years, considerable attention has been given to the development of microgenerators that are intended to be installed in domestic and similar premises. Such microgenerators are rated at up to 16 A per phase. At a nominal voltage to Earth (U_0) of 230 V, this corresponds to 3.68 kW on a single phase-supply or 11.04 kW on a three-phase supply.

A range of technologies have been developed to take account of the rather different technical and operational challenges that the domestic environment presents compared to more traditional small generator designs.

Not least of these is the importance of providing simple, safe and reliable products at a price that is in proportion to the consumer's reduction in electricity purchase costs, so offering an attractive payback.



Photo courtesy of Evoko Energy Ltd

Types of generation

It is, of course, possible to install and operate a generator and installation completely independently of the normal mains supply and to run certain appliances entirely on this separate system. This Guide, however, considers only generators that are intended to work in parallel with low voltage distribution systems, as this represents the most practical approach for most consumers.



Photo courtesy of Powergen

The assumption is that consumers generally will wish to continue to use electricity as and when required at the throw of a switch, without needing to be aware as to whether the generator is working or not.

Currently, the options can be divided into two broad classes from the point of view of connection into an existing installation:

- Renewable sources of electricity, powered by wind, light or hydro-power, or fuel cells. Many of these generate direct current (d.c.) and are connected to the mains through a d.c. to a.c. inverter
- Gas, oil and biomass fired micro-cogeneration (combined heat and power (CHP)) systems. The primary function of these systems is to provide for heating and hot water needs, in place of a traditional boiler or water heater. However, they include a small generator that provides electricity, powered by some of the heat energy produced for the water heating process. This Guide does not give guidance on the heat production aspects of microgenerators.

Renewable sources of heat using solar thermal panels, ground or air source heat pumps or biomass boilers that do not generate electricity are not covered by this Guide.

As previously mentioned, microgenerators are generally characterised as having an output of no more than 16 A per phase. In the case of microcogeneration (CHP) systems, because the electricity generation is ancillary to the heating of water and so represents only a part of the output of the system, the electrical output is typically in the range of 4 to 6 A.



© Baxi Heating UK Ltd 2008

Legal and related issues

When at work, even in domestic premises, an electrical installer is subject to relevant Health and Safety legislation, including the Electricity at Work Regulations.

Installers of microgenerators will need to be aware of the requirements of the relevant Building Regulations. In domestic premises in England and Wales, a person intending to carry out such work is required to give a building notice or deposit full plans for the installation of the microgenerator unless the work is carried out by a person registered with a self-certification scheme applicable to such work (as listed in Item 17 of Schedule 3 of the Building Regulations 2010). In Wales, the installation of solar photovoltaic power supply systems and small-scale generators remain notifiable activities under Part P.

In both England and Wales, the installation of a new circuit is notifiable under Part P of the Building Regulations

In Scotland, a Building Warrant may be required (further information is available at www.scotland.gov.uk/Topics/Built-Environment/Building/Building-standards).

Some forms of microgenerator may be subject to planning law and to the non-electrical aspects of the Building Regulations, in particular structural considerations.

Although an electrical installer might not be involved in such issues on behalf of his client, they may impact on an unwary electrical installer in carrying out his work.

Therefore, before commencing work, it is advisable to consider the issues covered below.

(A) The installation of renewable energy sources often requires planning permission. Therefore whether the proposed work is subject to these requirements or is considered 'permitted development' should be determined before the work commences. This is undertaken by contacting the local Planning Authority, who will, should planning permission be required, indicate what

information they require to be provided with the planning application.

In England and Wales, the relevant Building Regulations will normally apply to work in the domestic situation. Depending on the nature of this work, these regulations may cover electrical installations, various structural implications (such as the ability of the existing building to carry the additional load or forces produced at the fixing points in all weathers) and damp penetration issues, as appropriate. Compliance is achieved either through the appropriate 'Competent Person Scheme' or by applying to a building control body, such as the Local Authority Building Control. Further information can be obtained from the Planning Portal (www.planningportal.gov.uk).

- Before fixing microgeneration equipment to a building, consideration should be given by the installer to the structural condition of the building. This may involve a structural survey.
- In Scotland, a Building Warrant may be required.
- Hydro turbines may require planning consent and will also require a water abstraction licence.



Photo courtesy of Energy Saving Trust

(B) The Electricity Safety, Quality and Continuity Regulations 2002, as amended, contain, in regulation 22, requirements for the installation and operation of generators in parallel with the distributor's network. These generally prohibit the

connection of a generator without prior consent of the distributor (typically the relevant regional distribution network operator (DNO)), and contain requirements concerning design and operation that are likely to prevent parallel operation of generators in domestic premises.

However, an exemption is given in regulation 22(2) for the installation of generation rated up to a total of 16 A per phase, provided:

- it has protection that will disconnect from the mains supply automatically in the event of the loss of the mains supply
- the installation complies with the edition of BS 7671 (Requirements for Electrical Installations) current at the time of installation, and
- the installer notifies the DNO before or at the time of commissioning the microgenerator.

Details of the general requirements for connecting an SSEG and the characteristics for the protection scheme necessary to provide automatic disconnection following loss of mains or variation of voltage or frequency from the declared values are contained in the Energy Networks Association's Engineering Recommendation ER G83 (Issue 2: April 2012) and in BS EN 50438.

The installer should refer to the manufacturer's documentation to confirm that the microgenerator complies with the relevant requirements of ER G83 or BS EN 50438.

Details of the requirements for notifying the DNO before the time of commissioning the microgenerator are contained in ER G83 and in BS EN 50438.

In addition to notifying the DNO before or at the time of commissioning a microgenerator, the installer must provide the DNO with an Installation Commissioning Confirmation Form, a copy of the circuit diagram showing the circuit wiring, and the manufacturer's Verification Test Report, all within 28 days of the microgenerator being commissioned (clause 5.1.1 of ER G83 and Section A12 in Annex A of BS EN 50438 refer).

Where generation exceeding 16 A output in total is to be provided in a single installation, or where multiple microgeneration installations are to be installed in a close geographical region (such as in a housing development), it is necessary to obtain the permission of the DNO in advance.

Contract with the electricity supplier

Generators rated at up to 50 MW are exempted from licensing under the Utilities Act, so microgenerators covered by this Guide are exempt.



Energy users will have a contract with an electricity supplier for the purchase of electricity. Invariably the supply is provided through a meter. The meter will be either a prepayment meter (the customer pays in advance with cash or tokens) or a credit meter (the meter is read and the customer is billed retrospectively). In either case, the contract is for the supply of electricity to the premises.

If at any time the consumer's microgenerator generates more electrical power than is being used in the premises, the surplus will go into the electricity network.

The exporting of energy from the premises in this way will only be covered by the consumer's contract with the electricity supplier if a specific written agreement to that effect has been entered into by the consumer with the supplier, as will be the case if the customer applies to that supplier for the payment of Feed-in Tariffs.

Where this is the case, the electricity supplier may arrange for an export meter to be installed at the premises. However, where the installed capacity of the generator is less than 30 kW, the supplier may defer doing this until smart meters are rolled out.

In the absence of an export meter, the amount of energy exported will be deemed to be a percentage of the energy generated by the microgenerator. The energy generated will be ascertained from the generation meter, which forms part of the microgeneration installation. The fixed display unit of the generation meter must be installed in an accessible location so that the register can easily be read by the customer without having to use any tools, ladders or a torch. Ideally, the meter should be positioned adjacent to the consumer unit (MCS Metering Guidance V1.0).

The existing meter at the premises (the import meter) may not require replacement until smart meters are rolled out. However, the electricity supplier is likely to arrange for this meter to be replaced if it does not have a 'backstop' to prevent the energy register from running backwards during export, which would lead to double counting of exported energy.

In the unlikely circumstances that an agreement and the associated metering equipment are not in place for the export of electrical energy from the premises, the reverse flow of energy can have an impact on the supplier's electricity meter at the premises in one of the following ways:

- Where the meter is fitted with a backstop to prevent the energy register from running backwards, the consumer will receive no compensation for exported energy.
- Some meters with a backstop have a flag that is tripped by reverse power flow, which could result in the consumer being accused of stealing energy.
- A prepayment meter may have an internal contactor that cuts off the mains supply if the energy flow is reversed.

Some older meters do not have a backstop and the register will run backwards while energy is being exported, effectively 'crediting' the consumer with energy at the rate at which they normally pay for the electricity. This could be treated by the electricity supplier as a form of theft.

Electrical installation

Safety issues

Installing a microgenerator brings particular additional electrical safety concerns, which include the following:

- Persons must be warned that the electrical installation includes a microgenerator so that precautions can be taken to avoid the risk of electric shock. Both the mains supply and the microgenerator must be securely isolated before electrical work is performed on any part of the installation.
- Adequate labelling must be provided to warn that the installation includes another source of energy. Suitable labelling is suggested in ER G83 and, for photovoltaic systems, in The IET publication *Code of Practice for Grid Protected Solar Photovoltaic Systems*. These include a label warning the Fire and rescue service that a PV system is installed on the roof.
- It must be remembered that wind turbines are likely to produce an output whenever they are turning and PV cells will produce an output whenever they are exposed to light. Additional precautions, such as restraining the turbine from turning or adopting the means given in the IET Code of Practice to improve safety on the d.c. side of a PV system, will be necessary when working on those parts of the circuit close to the source of energy and upstream of the means of isolation.

In some respects, microgenerators can be considered to be similar to any current-using equipment. For example:

- live parts will invariably be insulated or have an earthed or insulating enclosure
- the metallic enclosure of a Class I microgenerator will need to be connected to the circuit protective conductor.

However, there are other aspects that require care to ensure that the existing level of electrical safety is maintained for the users following the installation of a microgenerator.

As mentioned previously, the exemption to the requirement for prior consent of the DNO, contained in Regulation 22(2) of the Electricity Safety, Quality and Continuity Regulations 2002, requires compliance with BS 7671 (DTI Publication reference - URN 02/1544, which gives guidance on the Electricity Safety, Quality and Continuity Regulations 2002, refers). Prior to commencing the installation of a microgenerator, the installer must confirm such compliance, for example, by examining a recent Electrical Installation Condition Report for the existing installation (if available), or by carrying out a Periodic Inspection.

In order for a microgenerator to be placed on the market, the manufacturer or supplier of the microgenerator is required to declare compliance with the Electrical Equipment (Safety) Regulations and the Electromagnetic Compatibility Regulations. The components of the microgenerator will be CE marked to confirm this. Also, for an MCS compliant installation, it is a requirement that the equipment being used has been certificated by a UKAS-accredited Certification Body where applicable (such as for the modules of a PV system). Inverters do not require such certification, but must be type-tested in accordance with the requirements given in Annex A1 of ER G83.

Compliance with these requirements should ensure that the microgenerator will be satisfactory in an installation in terms of the power factor, generation of harmonics, and voltage disturbances arising from starting current and synchronisation.

Any synchronising system should be automatic and of a type that considers frequency, phase and voltage magnitude. The microgenerator should also have documentation confirming, amongst other things, the acceptability of the means of protection against operation in the event of loss of the mains supply, as required by ER G83 or BS EN 50438.

In designing a connection for a microgenerator, the electrical installer has to consider all the issues that would need to be covered for a conventional final circuit, including:

- the maximum demand (and the generator output)
- the type of earthing arrangement
- the nature of the supply
- external influences
- compatibility, maintainability and accessibility
- protection against electric shock
- protection against thermal effects
- protection against overcurrent
- isolation and switching
- equipment selection and installation issues.

The electrical installer will recognise that some of these issues can be changed by the connection of a microgenerator to an existing installation.



Photo courtesy of GTEC Training Limited

It is unlikely with the size of microgenerators covered by this Guide that the prospective fault current would change sufficiently to exceed the fault rating of existing protective devices, but this should be confirmed.

From the specific perspective of a microgenerator, except for a PV system (see below), there are two connection options:

A) Connection into a separate dedicated circuit

B) Connection into an existing final circuit.

For a solar photovoltaic (PV) power supply system (including a PV microgeneration installation), the second option – connection into an existing final circuit – is not permitted by Regulation 712.411.3.2.1.1 of BS 7671.

Examples of the two options are shown diagrammatically in Fig 1.




Fig 1 – Examples of the two connection options for a microgenerator

Given the perceived constraint of financial viability on the development of the market for microgenerators, the second of these options has been considered by some product developers to offer a simple solution with minimal disruption to the consumer's property.

From the perspective of the electrical safety of the installation, however, this option can create design limitations for the installer of the microgenerator, and limitations for the user of the installation.

Connection into a dedicated circuit is preferred.

Connection to a dedicated circuit is technically simpler and creates least impact on existing use and hence on the user of the installation. The cost implication may not be significant when compared to the cost of the generator itself, and in some cases it may be less expensive in view of the need to meet the technical requirements detailed below for connecting into an existing final circuit.

Whichever of the two options is chosen, it is imperative that the safety of the electrical installation is not impaired by the installation of the microgenerator.

The essential criteria that must be met are given below for both options. In either case the following requirements must be met:

- i. The winding of an a.c. microgenerator must not be earthed (clause 6.4 of ER G83 and clause 4.1.3 of BS EN 50438 refer). The reason for this precaution is to avoid damage to the generator during faults on the distribution network and to ensure correct operation of protective devices.
Note. A d.c. source or d.c. microgenerator could be earthed provided the inverter separates the a.c. and d.c. sides by at least the equivalent of a transformer providing simple separation. Such earthing, which may be necessary for functional purposes in some cases, requires special consideration and is beyond the scope of this Guide.
- ii. Means must be provided to automatically disconnect the microgenerator from the mains supply in the event of loss of that supply or deviation of the voltage or frequency at the

supply terminals from the declared values. If the microgeneration installation includes a static inverter, the means must be on the load side of the inverter. (Regulation 551.7.4 of BS 7671 refers.)

Note. *The required protection settings for Great Britain are given in ER G83 and in Annex A of BS EN 50438.*

- iii. Means must also be provided to prevent the connection of the microgenerator to the mains supply in the event of loss of that supply or deviation of the voltage or frequency at the supply terminals from the declared values (Regulation 551.7.5 of BS 7671 refers).
Note. *The requirements are given in ER G83 and in BS EN 50438. Amongst other things, it is required that feeding power to the distribution network will only commence after the voltage and frequency on the distribution network have been within the limits of the interface protection settings for a minimum of 20 s for any generator system.*
- iv. Where a microgenerator having a d.c. source does not incorporate the equivalent of a transformer providing at least simple separation between the d.c. and a.c. sides, an RCD installed for fault protection by automatic disconnection of supply or for additional protection ($I_{\Delta n} \leq 30 \text{ mA}$) must be of a type that will operate as intended in the presence of d.c. components in the residual current. (This does not apply where it has been established – such as from a specific written statement given by the inverter manufacturer – that the inverter provides galvanic isolation between the d.c. and a.c. sides that prevents it from feeding d.c. current into the electrical installation.)
Note. *A Type AC RCD will not fulfil the above requirement. Depending on the level and form of d.c. components, an RCD (where required) will need to be of Type A to BS EN 61008 or BS EN 61009, Type B to BS EN 62423, or Type F to BS EN 62423. However, in the case of a PV power supply installation, Regulation 712.411.3.2.1.2 of BS 7671 stipulates that the RCD (where required) shall be of Type B.*
- v. Where a microgenerator is installed in a special installation or location covered by a specific

section of Part 7 of BS 7671, the requirements applicable to that special installation or location must also be applied as relevant to the microgenerator. For example, this might place limitations on the positioning of the microgenerator, involve additional protection with an RCD or supplementary bonding, or the selection of a microgenerator with a specified IP rating.

Additional design requirements for the two connection options

Connection of a microgenerator to a dedicated circuit (Fig 1(A) refers)

- vi. The basic design parameters for the circuit are:

$$I_b \geq I_g$$

where: I_b is the design current, and I_g is the rated output current of the microgenerator

$$I_n \geq I_b$$

where: I_n is the rated current of the overload protective device (Regulation 433.1.1(i) of BS 7671 refers)

disconnection of the circuit in the event of an earth fault on the circuit within:

- 5 s for TN systems, or
- 1 s for TT systems (Regulations 411.3.2.3 and 411.3.2.4 respectively of BS 7671 refer).

- vii. The circuit must connect to the supply side of the overcurrent protective device of each final circuit of the installation (Regulation 551.7.2, second line, refers). This can be achieved by connecting the circuit to a dedicated outgoing overcurrent protective device in the consumer unit.

- viii. Where a microgenerator is connected on the same side of an RCD as final circuits protected by that RCD, the RCD must disconnect the line and neutral conductors (Regulation 551.4.2 refers). For example, this applies to an RCD controlling a section of a consumer unit to which the dedicated circuit is connected via an outgoing way.

The reason for the above requirement is that if the RCD does not disconnect the neutral, protection no longer depends solely on the operation of the RCD but also the shutdown characteristics of the microgenerator, due to the existence of a current path similar to that shown in Fig 2.

It might be thought that the RCD need not disconnect the neutral if the dedicated circuit is connected to the consumer unit via an RCD, such as is mentioned in (ix). However, that is not the case, as that RCD would be unable to operate in response to current flowing to earth on its mains supply side, because (as mentioned in (i)) the winding of the microgenerator is not earthed.

- ix. Where the circuit requires RCD protection, such as may be the case where the circuit cable is concealed in a wall or partition (Regulations 522.6.202 and 522.6.203 refer), the RCD must be located at the consumer unit end of the cable (generally by using an RCBO as the dedicated protective device for the circuit).

There is no need to locate an RCD at the microgenerator end of the circuit too, provided that the winding of the microgenerator is not earthed (as should be the case – see (i)), as that RCD would be unable to detect a current flowing to earth supplied by the microgenerator.

- x. The microgenerator must be provided with means of isolation and of switching off for mechanical maintenance. (Regulation Groups 537.2 and 537.3, respectively, of BS 7671 refer. For PV systems, see also Regulation Group 712.537)

Note. See also 'Labelling and isolation', later in this Guide.

Connection of a microgenerator to an existing final circuit (Fig 1(B) refers)

(Not permitted for a PV power supply system – see 712.411.3.2.1.1)

xi. The basic design parameters for the circuit are as follows.

a) $I_z \geq I_n + I_g$

where: I_z is the current-carrying capacity of the conductors of the final circuit, I_n is the rated current of the overcurrent protective device, and I_g is the rated output current of the microgenerator (Regulation 551.7.2(i) of BS 7671 refers).

This may require the protective device to be replaced with one having a lower rated current.

b) The microgenerator must not be connected to the final circuit by means of a plug and socket-outlet (Regulation 551.7.2(ii) refers).

c) An RCD providing additional protection for the final circuit (where required) must disconnect all live (line and neutral) conductors (Regulation 551.7.1(ii) refers).

d) The line and neutral conductors of the final circuit or of the microgenerator must not be connected to Earth (Regulation 551.7.2(iii) refers). For example, as already stated in (i), the winding of the microgenerator must not be earthed.

e) The protective device providing fault protection for the final circuit must disconnect the line and neutral conductors. The only exception to this requirement is where it has been verified that in the event of an earth fault on the circuit, the operation of the protective device and the reduction of the voltage of the microgenerator to 50 V or less will both occur within the disconnection time required by Regulation 411.3.2 for the final circuit. (Regulation 551.7.2(iv) refers.)

f) The microgenerator must be provided with means of switching off for mechanical maintenance and of isolation from the remainder of the final circuit (Regulation Groups 537.2 and 537.3, respectively, refer).

Note. See also 'Labelling and isolation', later in this Guide.

The reason for the requirement in (xi) e) is that, if the protective device does not disconnect the neutral the effectiveness of the protection no

longer depends solely on the operation of the protective device, but also on the shutdown characteristics of the microgenerator.




Fig 2 – Example illustrating the reason for the requirement in (xi)e)

Fig 2 shows, as an example, an earth fault downstream of an RCBO with unswitched neutral. The earth fault causes operation of the RCBO, but the microgenerator can still supply current through the earth fault via the path shown in the diagram for a period until its own internal protection against loss of mains causes the microgenerator to shut down.

It should be noted that if the RCD element in the RCBO has been provided for additional protection, the arrangement shown above is not permitted as the RCBO would need to switch both the line and neutral conductors; see (xi) c).

Isolation and labelling

A microgenerator is a source of supply to the electrical installation. A main linked switch or linked circuit-breaker for this source must therefore be provided in a readily accessible position as near as practicable to the origin of the installation, such as adjacent to the consumer unit, as a means of switching off the supply on load and as a means of isolation (Regulations 132.15.201, 537.1.4 and 551.2.4 refer). The switch or circuit-breaker must disconnect the line and neutral conductors (Regulation 537.2.1.1 refers).

Means must also be provided to isolate the microgenerator from the public mains supply, as required by Regulation 551.7.6. This must be located at an accessible position within the installation, as required by clause 5.2 of ER G83.

The same means of isolation could be used for the purposes of both the previous two paragraphs, if it meets all the requirements referred to in those paragraphs.

In all instances, the means of isolation, which must be manual, must be capable of being secured in the 'off' isolating position (Regulation 537.2.1.2 refers).

Where a static inverter forms part of the microgenerator installation, a means of isolation must be installed on both sides of the inverter. However, this requirement does not apply on the power source side of an inverter that is integrated in the same enclosure as the power source. (Regulation 551.4.3.3.3 refers).


Isolation and switching devices in any d.c. circuits, such as on the d.c. side of a PV installation, must be of types suitable for d.c. use. Switchgear intended for a.c. circuits is often not suitable for d.c. or may need to be de-rated for such use. The manufacturer's specific advice in this respect should be obtained and followed.

To comply with the labelling requirements of Regulation 514.15.1 relating to alternative or additional sources of supply, and those of clause 6.2 of ER G83 and clause 5.4 of BS EN 50438, warning labels must be provided as a minimum at:

- the DNO's fused cutout
- the DNO's meter position
- the consumer unit(s)
- the output terminals of the microgenerator
- the points of isolation for the mains supply and the microgenerator supply.

In the case of a renewable source, such as PV cells or a wind turbine, a notice must be placed at the microgenerator isolator to warn that the conductors on the microgenerator side may remain live when the isolator is open.

The Health and Safety (Safety Signs and Signals) Regulations 1996 stipulate that the labels should display the prescribed triangular shape and font size using black on yellow colouring. A typical label is shown below.




The above label is reproduced from Clause 6.2 of G82/2

In addition, ER G83 requires up-to-date information to be displayed at the point of connection with a DNO's network as follows:

- A circuit diagram showing the relationship between the microgenerator and the DNO's fused cut-out. This diagram is also required to show by whom the generator is owned and maintained.

- A summary of the separate settings of the protection incorporated within the equipment. The figure below is an example of the type of circuit diagram that needs to be displayed. This diagram is for illustrative purposes and not intended to be fully descriptive.



The installer is required to advise the customer that it is the customer's responsibility to ensure that this safety information is kept up to date.

The installation operating instructions must contain the manufacturer's contact details, such as name, telephone number and web address.

ANNEX 1

Glossary/Definitions:

Combined heat and power (CHP)

Process that generates heat some of which provides the motive power to a microgenerator that is part of the heat generating device

Distribution network operator (DNO)

The person or legal entity named in Part 1 of the Distribution Licence and any permitted legal assigns or successors in title of the named party

Electricity supplier

(a) A person supplying electricity under an Electricity Supply Licence; or

(b) A person supplying electricity under exemption under the Act; in each case acting in its capacity as a supplier of electricity to Customers in Great Britain.

Export meter

A meter, complying with the appropriate meter legislation, which measures the amount of electricity being exported to the electricity network

Generation meter

A meter which the energy user is responsible for, complying with the appropriate meter legislation, and which measures the quantity of electricity generated by the energy user's generation unit

Microgenerator

A device rated at up to 16 A per phase designed for the small-scale production of heat and/or electricity from a low carbon source (based on the definition in section 82 of the Energy Act 2004)

Network

Low voltage electrical lines and equipment owned or operated by a DNO that are used to distribute electricity to consumers

RCBO

An electromechanical protective device intended to provide overcurrent protection and residual current protection

SSEG

(Small Scale Embedded Generation/Generator) microgenerator

Type AC RCD

An RCD intended to operate for residual sinusoidal alternating currents, whether suddenly applied or slowly rising.

Type A RCD

An RCD intended to operate for the following forms of residual current, whether suddenly applied or slowly rising:

- residual sinusoidal alternating currents
- residual pulsating direct currents
- residual pulsating direct currents superimposed on a smooth direct current of 6 mA.

Type B RCD

An RCD intended to operate for the following forms of residual current, whether suddenly applied or slowly rising:

- residual sinusoidal alternating currents up to 1000 Hz
- residual alternating currents superimposed on a smooth direct current of 0.4 times the rated residual operating current
- residual pulsating direct currents superimposed on a smooth direct current of 0.4 times the rated residual operating current
- residual direct currents which may result from rectifying circuits.

Type F RCD

An RCD intended for installations where frequency inverters are supplied between line and neutral or line and earthed middle conductor, and able to provide protection in the event of alternating residual sinusoidal currents at the rated frequency, pulsating direct residual currents and composite residual currents that may occur.

ANNEX 2

British Standards and other standards referred to:

British Standards

BS 7671

Requirements for electrical installations. IET Wiring Regulations. Seventeenth edition (as amended)

BS EN 50438

Requirements for micro-generating plants to be connected in parallel with public low-voltage distribution networks

BS EN 61008

Residual current operated circuit-breakers without integral overcurrent protection for household and similar uses (RCCBs).

BS EN 61009

Residual current operated circuit-breakers with integral overcurrent protection for household and similar uses (RCBOs).

Other standards

BS EN 62423

Type F and type B residual current operated circuit-breakers with and without integral overcurrent protection for household and similar uses.



The latest versions of all the **BestPracticeGuides** are available to download from www.electricalsafetyfirst.org.uk

Electrical Safety First

Unit 331, Metal Box Factory, 30 Great Guildford Street, London SE1 0HS

Helpline: 020 3463 5100

Email: enquiries@electricalsafetyfirst.org.uk Web: www.electricalsafetyfirst.org.uk

Registered Charity (England and Wales) No.257376 (Scotland) No. SC039990

Electrical Safety First is the UK charity dedicated to reducing deaths and injuries caused by electrical accidents. Our aim is to ensure everyone in the UK can use electricity safely

**Electrical
Safety First**
The UK's electrical safety experts